

Intel vPro® Technology: How to Create an Intel® AMT Profile in Intel® EMA

intel.

1. Log in to Intel® Endpoint Management Assistant (Intel EMA) as the tenant administrator.

2. On the left panel, click **Endpoint Groups**, and then click **Intel AMT Profiles** at the top.

3. Click **New Intel AMT Profile**.

4. In the **General** section, it is important to specify the profile name, client initiated remote access (CIRA), and a nonresolvable and inexistent domain name server (DNS) for the CIRA intranet domain suffix.

5. After you complete the **General** section, go to **Management Interfaces**, and select all the features. This is where you enable key features including keyboard, video, and mouse (KVM) redirection, web-based user interface (UI), and IDE/USB redirection for rebooting from an alternate drive.

6. In the Wi-Fi section, be sure the boxes for both **Synchronize with the host platform WiFi profiles** and **Enable WiFi connection in all system power states (S1-S5)** are selected, and then click **Save**.

To learn more about how to complete these steps, read:

“For IT: A How-to Guide to the Intel vPro® Platform”

intel.

Intel technologies may require enabled hardware, software or service activation.

No product or component can be absolutely secure.

Your costs and results may vary.

© Intel Corporation. Intel, the Intel logo, and other Intel marks are trademarks of Intel Corporation or its subsidiaries. Other names and brands may be claimed as the property of others.

Printed in USA 1121/GA/PRW/PDF Please Recycle 349332-001US